



S1 RANGE SWITCH						
	A	B	C	D	E	F
POS. 1 - IV, 1MA, RX I	11-6	1-2	1-11	7-12	4-2	7-8
POS. 2 - 3V, 3MA, RX IO	11-7	1-3	1-11	7-12	4-3	7-9
POS. 3 - 10V, 10MA, RX I00	11-8	—	1-11-4	7-12	4-2	7-10
POS. 4 - 30V, 30MA, RX I K	11-8	1-5	1-11	7-12	4-3	7-11
POS. 5 - 100V, 100MA, RX I00K	11-10	—	1-11-6	7-12	4-2	7-12
POS. 6 - 300V, 300MA, RX I000K	11-10	1-7	10-11	2-12	4-3	7-1
POS. 7 - 1KV, 1A, RX I M	11-12	—	10-11 1-8	3-12	4-2	7-2

S2 FUNCTION SWITCH				
	A	B	C	D
POS. 1 - OHMS	9-10-11	12-2	2-6	8-9 1-3
POS. 2 - VOLTS	—	5-7 12-3	9-10 6-7	1-4
POS. 3 - MA	—	5-8 12-1-4	9-10 6-7	1-5

S3 MODE SWITCH				
	A	B	C	D
POS. 1 - OFF	4-5	2-7	12-1	—
POS. 2 - AC	9-10 4-2	6-7	10-11 12-1	8-9 3-4
POS. 3 - DC	9-10	1-2	6-7 12-1	8-9 3-4
POS. 4 - +DC	9-10 4-2	1-7	6-7 12-1	8-9 3-4

- NOTES:
1. RESISTOR VALUES ARE IN OHMS, 1/2 WATT, 1% UNLESS OTHERWISE SPECIFIED.
  2. CAPACITOR VALUES ARE IN MICROFARADS UNLESS OTHERWISE SPECIFIED.
  3. SWITCH LUGS WITH — ARE DUMMY TERMINALS AND ARE USED ONLY AS TIE POINTS.
  4. ALL SWITCHES ARE VIEWED FROM SHAFT END AND ARE IN EXTREME CCW POSITION.
  5. THE FOLLOWING SWITCH LUGS ARE CONNECTED TO EACH OTHER: S2C-9 TO S2D-9, S3A-2 TO S3B-2; S3A-7 TO S3B-7.